

MultiConnect™ PCIe

MTPCIE-H5/MTPCIE-BW Developer Guide

MultiConnect PCIe Developer Guide

Models: MTPCIE-H5-xx, MTPCIE-H5-V-BW, MTPCIE-BW

Part Number: S000572, Version 1.3 European Edition

Copyright

This publication may not be reproduced, in whole or in part, without the specific and express prior written permission signed by an executive officer of Multi-Tech Systems, Inc. All rights reserved. **Copyright © 2013 by Multi-Tech Systems, Inc.**

Multi-Tech Systems, Inc. makes no representations or warranties, whether express, implied or by estoppels, with respect to the content, information, material and recommendations herein and specifically disclaims any implied warranties of merchantability, fitness for any particular purpose and non-infringement.

Multi-Tech Systems, Inc. reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of Multi-Tech Systems, Inc. to notify any person or organization of such revisions or changes.

Trademarks

Multi-Tech, SocketModem, and the Multi-Tech logo are registered trademarks of Multi-Tech Systems, Inc. MultiConnect is a trademark of Multi-Tech System. All other brand and product names are trademarks or registered trademarks of their respective companies.

Legal Notices

The Multi-Tech products are not designed, manufactured or intended for use, and should not be used, or sold or re-sold for use, in connection with applications requiring fail-safe performance or in applications where the failure of the products would reasonably be expected to result in personal injury or death, significant property damage, or serious physical or environmental damage. Examples of such use include life support machines or other life preserving medical devices or systems, air traffic control or aircraft navigation or communications systems, control equipment for nuclear facilities, or missile, nuclear, biological or chemical weapons or other military applications (“Restricted Applications”). Use of the products in such Restricted Applications is at the user’s sole risk and liability.

MULTI-TECH DOES NOT WARRANT THAT THE TRANSMISSION OF DATA BY A PRODUCT OVER A CELLULAR COMMUNICATIONS NETWORK WILL BE UNINTERRUPTED, TIMELY, SECURE OR ERROR FREE, NOR DOES MULTI-TECH WARRANT ANY CONNECTION OR ACCESSIBILITY TO ANY CELLULAR COMMUNICATIONS NETWORK. MULTI-TECH WILL HAVE NO LIABILITY FOR ANY LOSSES, DAMAGES, OBLIGATIONS, PENALTIES, DEFICIENCIES, LIABILITIES, COSTS OR EXPENSES (INCLUDING WITHOUT LIMITATION REASONABLE ATTORNEYS FEES) RELATED TO TEMPORARY INABILITY TO ACCESS A CELLULAR COMMUNICATIONS NETWORK USING THE PRODUCTS.

The Multi-Tech products and the final application of the Multi-Tech products should be thoroughly tested to ensure the functionality of the Multi-Tech products as used in the final application. The designer, manufacturer and reseller has the sole responsibility of ensuring that any end user product into which the Multi-Tech product is integrated operates as intended and meets its requirements or the requirements of its direct or indirect customers. Multi-Tech has no responsibility whatsoever for the integration, configuration, testing, validation, verification, installation, upgrade, support or maintenance of such end user product, or for any liabilities, damages, costs or expenses associated therewith, except to the extent agreed upon in a signed written document. To the extent Multi-Tech provides any comments or suggested changes related to the application of its products, such comments or suggested changes is performed only as a courtesy and without any representation or warranty whatsoever.

Contacting Multi-Tech

Knowledge Base

The Knowledge Base provides immediate access to support information and resolutions for all Multi-Tech products. Visit <http://www.multitech.com/kb.go>.

Support Portal

To create an account and submit a support case directly to our technical support team, visit: <https://support.multitech.com>.

Support

Business Hours: M-F, 9am to 5pm CT

| Country | By Email | By Phone |
|------------------------------|--|----------------------------------|
| Europe, Middle East, Africa: | support@multitech.co.uk | +(44) 118 959 7774 |
| U.S., Canada, all others: | support@multitech.com | (800) 972-2439 or (763) 717-5863 |

Warranty

To read the warranty statement for your product, visit www.multitech.com/warranty.go. For other warranty options, visit www.multitech.com/es.go.

World Headquarters

Multi-Tech Systems, Inc.
 2205 Woodale Drive, Mounds View, MN 55112
 Phone: (800) 328-9717 or (763) 785-3500
 Fax (763) 785-9874

Contents

| | |
|--|-----------|
| Product Overview | 6 |
| About MultiConnect PCIe..... | 6 |
| Documentation | 6 |
| Developer Kit Contents | 6 |
| Attaching Power Supply Blades | 6 |
| Power Supply and Blades..... | 6 |
| Attaching the Blades | 7 |
| Pinout | 8 |
| Multi-Tech Mini PCIe Pinout | 8 |
| Standard Mini-PCI Express Pinout | 11 |
| Pinout for Cellular USB Only | 13 |
| Design Considerations..... | 14 |
| Design Consideration | 14 |
| Noise Suppression Design | 14 |
| PC Board Layout Guideline | 14 |
| Electromagnetic Interference | 14 |
| Electrostatic Discharge Control..... | 15 |
| USB Design | 15 |
| Developer Board and Schematics..... | 16 |
| Developer Board | 16 |
| Assembly Diagram..... | 18 |
| Top | 18 |
| Bottom | 19 |
| Developer Board Block Diagram | 20 |
| Developer Board Schematics | 21 |
| Board Components | 30 |
| Installing a Communications Device onto the Board..... | 31 |
| Installing a SIM Card onto the Board | 31 |
| Making Other Board Connections..... | 31 |
| Safety Notices and Warnings | 32 |
| Radio Frequency (RF) Safety | 32 |
| Vehicle Safety..... | 32 |
| User Responsibility..... | 32 |
| Device Maintenance | 32 |
| Labeling Requirements | 34 |
| Approvals and Certification..... | 34 |
| Example HSPA+ H5 Label | 34 |

| | |
|---|-----------|
| Regulatory Statements | 35 |
| R&TTE Directive Compliance | 35 |
| Restriction of the Use of Hazardous Substances (RoHS) | 36 |
| International Modem Restrictions | 36 |
| Other Countries..... | 36 |
| Environmental Notices | 37 |
| Waste Electrical and Electronic Equipment Statement | 37 |
| WEEE Directive..... | 37 |
| Instructions for Disposal of WEEE by Users in the European Union | 37 |
| Information on HS/TS Substances According to Chinese Standards | 38 |
| Information on HS/TS Substances According to Chinese Standards (in Chinese) | 39 |
| Antennas, Cables, GPS | 40 |
| Antenna System Cellular Devices..... | 40 |
| PTCRB Antenna Requirements | 40 |
| HSPA+/ UMTS Antenna Information..... | 40 |
| GPS Antennas..... | 41 |
| Bluetooth Antenna Specifications..... | 41 |
| Wi-Fi Antennas..... | 41 |
| Device Overview | 43 |
| Description | 43 |
| Product Build Options | 43 |
| Account Activation for Cellular Devices | 43 |
| Bluetooth/Wi-Fi | 43 |
| Mechanical Drawing | 45 |
| MTPCIE-H5-xx..... | 45 |
| MTPCIE-BW | 46 |
| Specifications | 47 |
| MTPCIE-H5 Specifications | 47 |
| MTPCIE-H5 DC Electrical Characteristics..... | 49 |
| Absolute Maximum Rating..... | 49 |
| PCIe Connector Leads | 50 |
| Typical Power Flow | 55 |
| Power Measurements..... | 56 |
| MTPCIE-H5 | 56 |
| MTPCIE-H5-V-BW | 56 |
| MTPCIE-BW | 56 |
| Device Configuration | 57 |
| Device Configuration Notes | 57 |
| Application Notes | 58 |
| RF Performances | 58 |

| | |
|--|-----------|
| Receiver Features for Cellular Devices | 58 |
| RF connection and antenna | 58 |
| Frequency Bands | 59 |
| Installing Drivers for Non-UIP HSPA+ Devices..... | 60 |
| HSPA+ Device Driver Installation | 60 |
| Installing on Linux | 60 |
| Windows Release Notes | 61 |
| Downloading the Windows USB Driver | 61 |
| Windows Notes | 61 |
| Installing on Windows 8, 7 or Vista | 62 |
| Installing on Windows XP | 63 |
| Uninstalling Windows Drivers | 64 |
| Remove Microsoft Installed Drivers..... | 64 |
| Developer Note | 65 |
| Using Linux with H5 Devices | 66 |
| Shell Commands..... | 66 |
| Testing Serial Ports..... | 66 |
| Create a PPP Connection | 66 |
| Example..... | 66 |
| C Programming..... | 67 |
| open()..... | 67 |
| read()..... | 68 |
| write()..... | 69 |
| close()..... | 69 |
| Test Program() | 70 |
| Bluetooth Developer Information | 72 |
| Configuring the MTPCIE-DK1 Developer Board | 72 |
| Calibrating Wi-Fi and Programming the MAC Address | 72 |
| Creating a PPP Connection..... | 72 |
| Setting Wi-Fi Access Point with an MT100EOCG and an MTPCIE Bluetooth/Wi-Fi..... | 72 |
| Example Wi-Fi Access Point Script | 73 |
| Using an MT100EOCG with an MTPCIE Bluetooth/Wi-Fi Device as Wi-Fi Client | 74 |
| Setting up Bluetooth with an MT100 EOCG and an MTPCIE Bluetooth/Wi-Fi Device | 75 |
| Setting up an External USB to MTPCIE Bluetooth Serial Interface | 75 |
| Index..... | 78 |

Product Overview

About MultiConnect PCIe

The MultiConnect™ PCIe embedded cellular modem is a complete, ready-to-integrate communications device that offers standard-based penta-band HSPA+ 21, dual-band EV-DO Rev A, or CDMA performance. This quick-to-market communications device allows developers to add wireless communication and GPS tracking to products with a minimum of development time and expense. The MultiConnect PCIe embedded cellular modem is based on industry-standard open interfaces and utilizes a PCI Express Mini Card form factor.

Documentation

The following documentation is available by email to oemsales@multitech.com or by using the Developer Guide Request Form at www.multitech.com.

- **MultiConnect PCIe Developer Guide** – This document. Provides an overview, safety and regulatory information, design considerations, schematics, and device information for developers.
- **AT Command Guide** – Device specific AT command reference guide.

Developer Kit Contents

Your Developer Kit (MTPCIE-DK1) includes the following:

| | |
|------------------|---|
| Developer Board | 1 - MTPCIE-DK Developer Board |
| Power Supply | 1 - 100-240V 9V-1.7A power supply with removable blades, 1 - US blade/plug, 1 - EURO blade/plug, 1 - UK blade/plug |
| Cables | 1 - RS-232 DB9F-DB9M serial cable, 1 - RJ-45 Ethernet cable, 2 -USB cable 2 - SMA-to-UFL antenna cables (1 - for cellular, 1 - for GPS) 1 - RSMA-to-UFL antenna cable for Bluetooth/Wi-Fi |
| Antennas | 1 - 3.3V magnetic GPS antenna , 1 - HEPTA band SMA antenna, 1 - 2.4GHz, dipole Wi-Fi antenna |
| Customer Notices | Modem activation notice |
| Additional | One promotional screwdriver |

Attaching Power Supply Blades

Power Supply and Blades

If your device shipped with a power cord, attach the blades for your region.



Power Supply No
Blades



Power Supply with
EU blad



Power Supply with
NAM blade




Power Supply with
UK blade

Attaching the Blades

To attach a power supply blade:

1. Remove the power supply cover (not shown). To do this, slide the lock down and hold it while you lift off the cover.
2. Insert the latch on the blade into the notch on the power supply.
3. Slide the lock down and hold it while you press the blade in place. Then, release it.



- 1 - Latch
- 2 - Notch
- 3 - Sliding lock

Pinout

Multi-Tech Mini PCIe Pinout

Note:

Some modems do not include all the pins shown above. Refer to your model's Device Guide for model specific pinout information.

SDIO can operate up to 25Mhz. Treat the SDIO traces to Host like a bus and keep the bus length as short as possible. Multi-Tech recommends adding series termination resistors on all the SDIO traces.

| Pin # | Name | I/O | Function | MTPCIE-H5 | MTPCIE-H5-V-BW | MTPCIE-BW |
|-------|----------|-----|---------------------------------|-----------|----------------|-----------|
| 1 | SDIO_D0 | I/O | Wi-Fi SDIO_D0 | | X | X |
| 2 | 3.3Vaux | I | 3.3Vaux | X | X | X |
| 3 | SDIO_D1 | I/O | Wi-Fi SDIO_D1 | | X | X |
| 4 | GND | | Ground | X | X | X |
| 5 | SDIO_D2 | I/O | Wi-Fi SDIO_D2 | | X | X |
| 6 | BT_TXD | I | Bluetooth Transmit data | | X | X |
| 7 | SDIO_D3 | I/O | Wi-Fi SDIO_D3 | | X | X |
| 8 | BT_RTS | I | Bluetooth RTS | | X | X |
| 9 | GND | | Ground | X | X | X |
| 10 | BT_CTS | O | Bluetooth CTS | | X | X |
| 11 | SDIO_CMD | I/O | Wi-Fi SDIO_CMD | | X | X |
| 12 | BT_RXD | O | Bluetooth Receive data | | X | X |
| 13 | SDIO_CLK | I | Wi-Fi SDIO_CLK | | X | X |
| 14 | BT_EN | I | Bluetooth enable (low disable) | | X | X |
| 15 | GND | | Ground | X | X | X |
| 16 | GPIO_2 | I/O | 3G Cellular General purpose I/O | | X | |
| 17 | WLAN_EN | I | Wi-Fi enable (low disable) | | X | X |
| 18 | GND | | Ground | X | X | X |
| 19 | WLAN_IRQ | O | Wi-Fi interrupt (low active) | | X | X |
| 20 | 3G_ONOFF | I | 3G Cellular On/Off (low active) | X | X | |

| Pin # | Name | I/O | Function | MTPCIE-H5 | MTPCIE-H5-V-BW | MTPCIE-BW |
|-------|------------|-----|--|-----------|----------------|-----------|
| 21 | GND | | Ground | X | X | X |
| 22 | 3G_RST | I | 3G Cellular Reset line (low active) | X | X | |
| 23 | 1.8V | O | 1.8V output | | X | X |
| 24 | 3.3Vaux | I | 3.3Vaux | X | X | X |
| 25 | GPIO_1 | I/O | Bluetooth General purpose I/O | | X | X |
| 26 | GND | | Ground | X | X | X |
| 27 | GND | | Ground | X | X | X |
| 28 | 3G_DVI_WA0 | I/O | 3G Cellular digital voice control line | | X | |
| 29 | GND | | Ground | X | X | X |
| 30 | 3G_DVI_CLK | I/O | 3G Cellular digital voice clock | | X | |
| 31 | 3G_DVI_RX | I | 3G Cellular digital voice receive | | X | |
| 32 | RI | O | 3G Cellular UART RI | | X | |
| 33 | 3G_DVI_TX | O | 3G Cellular digital voice transmit | | X | |
| 34 | GND | | Ground | X | X | X |
| 35 | GND | | Ground | X | X | X |
| 36 | USB_D- | I/O | 3G USB Negative Data | X | X | |
| 37 | GND | | Ground | X | X | X |
| 38 | USB_D+ | I/O | 3G USB Positive Data | X | X | |
| 39 | 3.3Vaux | I | 3.3Vaux | X | X | X |
| 40 | GND | | Ground | X | X | X |
| 41 | 3.3Vaux | I | 3.3Vaux | X | X | X |
| 42 | LED_WWAN# | O | 3G Cellular STAT LED Output | X | X | |
| 43 | GND | | Ground | X | X | X |
| 44 | DCD | O | 3G Cellular UART DCD | | X | |
| 45 | CTS | O | 3G Cellular UART CTS | | X | |
| 46 | GPIO_3 | I/O | 3G Cellular General purpose I/O | | X | |
| 47 | RTS | I | 3G Cellular UART RTS | | X | |

| Pin # | Name | I/O | Function | MTPCIE-H5 | MTPCIE-H5-V-BW | MTPCIE-BW |
|-------|---------|-----|-----------------------------------|-----------|----------------|-----------|
| 48 | DTR | I | 3G Cellular UART DTR | | X | |
| 49 | RXD | O | 3G Cellular UART Receive data | | X | |
| 50 | GND | | Ground | X | X | X |
| 51 | TXD | I | 3G Cellular UART transmit data | | X | |
| 52 | 3.3Vaux | I | 3.3Vaux | X | X | X |

Standard Mini-PCI Express Pinout

| Pin # | Function | I/O | Description |
|-------|------------|-----|--|
| 1 | WAKE# | O | WAKE |
| 2 | 3.3Vaux | I | 3.3Vaux |
| 3 | COEX1 | I | Co-existence pin, not defined |
| 4 | GND | | GND |
| 5 | COEX2 | I | Co-existence pin, not defined |
| 6 | 1.5V | I | 1.5V |
| 7 | CLKREQ# | O | CLKREQ# |
| 8 | UIM_PWR | I | UIM_PWR |
| 9 | GND | | GND |
| 10 | UIM_DATA | I/O | UIM_DATA |
| 11 | REFCLK+ | I | PCI Express reference clock |
| 12 | UIM_CLK | I | UIM_CLK |
| 13 | REFCLK- | I | PCI Express reference clock |
| 14 | UIM_RESET | I | UIM_RESET |
| 15 | GND | | GND |
| 16 | UIM_VPP | O | UIM_VPP |
| 17 | Reserved | | Reserved |
| 18 | GND | | GND |
| 19 | Reserved | | Reserved |
| 20 | W_DISABLE# | I | W_DISABLE# |
| 21 | GND | | GND |
| 22 | PERST# | I | PERST# |
| 23 | PERn0 | O | PCI Express receiver differential pair signal |
| 24 | 3.3Vaux | I | 3.3Vaux |
| 25 | PERp0 | O | PCI Express receiver differential pair signal |
| 26 | GND | | GND |
| 27 | GND | | GND |
| 28 | 1.5V | I | 1.5V |
| 29 | GND | | GND |
| 30 | SMB_CLK | I | SMB_CLK |
| 31 | PETn0 | I | PCI Express transmitter differential pair signal |
| 32 | SMB_DATA | I/O | SMB_DATA |

| Pin # | Function | I/O | Description |
|-------|-----------|-----|--|
| 33 | PETp0 | I | PCI Express transmitter differential pair signal |
| 34 | GND | | GND |
| 35 | GND | | GND |
| 36 | USB_D- | I/O | USB Negative Data |
| 37 | GND | | GND |
| 38 | USB_D+ | I/O | USB Positive Data |
| 39 | 3.3Vaux | I | 3.3Vaux |
| 40 | GND | | GND |
| 41 | 3.3Vaux | I | 3.3Vaux |
| 42 | LED_WWAN# | O | LED Output |
| 43 | GND | | GND |
| 44 | LED_WLAN# | O | LED Output |
| 45 | Reserved | | Reserved |
| 46 | LED_WPAN# | O | LED Output |
| 47 | Reserved | | Reserved |
| 48 | 1.5V | I | 1.5V |
| 49 | Reserved | | Reserved |
| 50 | GND | | GND |
| 51 | Reserved | | Reserved |
| 52 | 3.3Vaux | I | 3.3Vaux |

Pinout for Cellular USB Only

| Pin # | Name | I/O | Description |
|-------|----------|-----|-----------------------------|
| 2 | 3.3 Vaux | I | 3.3 Vaux |
| 4 | GND | | Ground |
| 9 | GND | | Ground |
| 15 | GND | | Ground |
| 18 | GND | | Ground |
| 20 | 3G_ONOFF | I | 3G cellular on/off |
| 21 | GND | | Ground |
| 22 | 3G_RST | I | 3G cellular reset line |
| 24 | 3.3 Vaux | I | 3.3 Vaux |
| 26 | GND | | Ground |
| 27 | GND | | Ground |
| 29 | GND | | Ground |
| 35 | GND | | Ground |
| 36 | USB_D- | I/O | 3G USB Negative Data |
| 37 | GND | | Ground |
| 38 | USB_D+ | I/O | 3G USB Positive Data |
| 39 | 3.3 Vaux | I | 3.3 Vaux |
| 40 | GND | | Ground |
| 41 | 3.3 Vaux | I | 3.3 Vaux |
| 42 | LED_WWAN | O | 3G Cellular STAT LED Output |
| 43 | GND | | Ground |
| 50 | GND | | Ground |
| 52 | 3.3 Vaux | I | 3.3 Vaux |

Design Considerations

Design Consideration

When using the Multi-Tech MiniPCIe form factor:

- Consult your modem's device guide for device dimensions. With the modem, the Multi-Tech Mini PCIe form factor exceeds the standard Mini PCIe maximum component height for top and bottom.
- If you need to install components under the module, use taller connectors to avoid conflict. Multi-Tech recommends not installing components under the module.
- Check the Pinout table for pins that differ from the MiniPCIe spec.

Noise Suppression Design

Adhere to engineering noise-suppression practices when designing a printed circuit board (PCB) containing the MultiConnect PCIe. Noise suppression is essential to the proper operation and performance of the modem and surrounding equipment.

Any OEM board design that contains the MultiConnect PCIe should consider both on-board and off-board generated noise that can affect digital signal processing. Both on-board and off-board generated noise that is coupled on-board can affect interface signal levels and quality. Noise in frequency ranges that affect modem performance is of particular concern.

On-board generated electromagnetic interference (EMI) noise that can be radiated or conducted off-board is equally important. This type of noise can affect the operation of surrounding equipment. Most local government agencies have stringent certification requirements that must be met for use in specific environments.

Proper PC board layout (component placement, signal routing, trace thickness and geometry, etc.) component selection (composition, value, and tolerance), interface connections, and shielding are required for the board design to achieve desired modem performance and to attain EMI certification.

Other aspects of proper noise-suppression engineering practices are beyond the scope of this guide. Consult noise suppression techniques described in technical publications and journals, electronics and electrical engineering text books, and component supplier application notes.

PC Board Layout Guideline

In a 4-layer design, provide adequate ground plane covering the entire board. In 4-layer designs, power and ground are typically on the inner layers. All power and ground traces should be 0.05 inches wide.

Electromagnetic Interference

The following guidelines are offered specifically to help minimize EMI generation. Some of these guidelines are the same as, or similar to, the general guidelines. To minimize the contribution of device-based design to EMI, you must understand the major sources of EMI and how to reduce them to acceptable levels.

- Keep traces carrying high frequency signals as short as possible.
- Provide a good ground plane or grid. In some cases, a multilayer board may be required with full layers for ground and power distribution.
- Decouple power from ground with decoupling capacitors as close to the device's power pins as possible.

- Eliminate ground loops, which are unexpected current return paths to the power source and ground.
- Decouple the power cord at the power cord interface with decoupling capacitors. Methods to decouple power lines are similar to decoupling telephone lines.
- Locate high frequency circuits in a separate area to minimize capacitive coupling to other circuits.
- Locate cables and connectors to avoid coupling from high frequency circuits.
- Lay out the highest frequency signal traces next to the ground grid.
- If using a multilayer board design, make no cuts in the ground or power planes and be sure the ground plane covers all traces.
- Minimize the number of through-hole connections on traces carrying high frequency signals.
- Avoid right angle turns on high frequency traces. Forty-five degree corners are good; however, radius turns are better.
- On 2-layer boards with no ground grid, provide a shadow ground trace on the opposite side of the board to traces carrying high frequency signals. This will be effective as a high frequency ground return if it is three times the width of the signal traces.
- Distribute high frequency signals continuously on a single trace rather than several traces radiating from one point.

Electrostatic Discharge Control

Handle all electronic devices with certain precautions to avoid damage due to the static charge accumulation.

See the ANSI/ESD Association Standard (ANSI/ESD S20.20-1999) – a document “for the Development of an Electrostatic Discharge Control for Protection of Electrical and Electronic Parts, Assemblies and Equipment.” This document covers ESD Control Program Administrative Requirements, ESD Training, ESD Control Program Plan Technical Requirements (grounding/bonding systems, personnel grooming, protected areas, packaging, marking, equipment, and handling), and Sensitivity Testing.

Multi-Tech Systems, Inc. strives to follow all of these recommendations. Input protection circuitry has been incorporated into the Multi-Tech devices to minimize the effect of static buildup, take proper precautions to avoid exposure to electrostatic discharge during handling.

Multi-Tech uses and recommends that others use anti-static boxes that create a faraday cage (packaging designed to exclude electromagnetic fields). Multi-Tech recommends that you use our packaging when returning a product and when you ship your products to your customers.

USB Design

Multi-Tech recommends consulting Intel's High Speed USB Platform Design Guidelines for information about USB signal routing, impedance, and layer stacking. Also:


- Shield USB cables with twisted pairs (especially those containing D+/D-).
- Use a single 5V power supply for USB devices. Consult your model's Device Guide for Power Draw section for current (ampere) requirements.
- Route D+/D- together in parallel with the trace spacing needed to achieve 90 ohms differential impedance for the USB pair and to maintain a 20 mil space from the USB pair and all other signals.
- If power is provided externally, use a common ground between the carrier board and the device.



Developer Board and Schematics

Note: Third-party components shown in the following drawings are included as examples only.

Developer Board


This developer board drawing shows the major board components.






Assembly Diagram


Top




Bottom




Developer Board Block Diagram




Developer Board Schematics





| | | | |
|--|-----------------|----------|--|
| Build Level | | Charge # | |
| <Variant Name> | | 03 | |
| Size | Discount Number | Rev | |
| B | 357 | B | |
| File | | Sheet | |
| MTPCIE-DK1 | | 4 of 11 | |
| <p>-NOTICE- This drawing may contain proprietary and confidential information. It is the property of Multi-Tech Systems, Inc. and shall remain the property of Multi-Tech Systems, Inc. It may not be reproduced in whole or in part without written consent. The drawing is to be retained indefinitely. Circulate when printed.</p> | | | |
| | | | |




NOTICE:
This drawing may contain proprietary and confidential information and remains the property of Multi-Tech Systems, Inc. It may not be used, copied, or reproduced in any form without the prior written consent of Multi-Tech Systems, Inc. All rights reserved. Drawing is to be returned upon request. Unclassified when printed.




MTPCIE-DK1

| | | | |
|-------------|---|-----------------|------------|
| BUILD Level | | <Variant Name> | Change Kit |
| Size | B | Document Number | 03 |
| Rev | B | 357 | Rev |



| | | | | |
|------------|---|-----------------|----------------|-----------|
| MTPCIE-DK1 | | Build Level | <Variant Name> | Change to |
| Size | B | Document Number | 357 | Rev |
| Sheet | 6 | of | 11 | |



Board Components

| Jumper | Description |
|------------------------------------|--|
| JP3, JP4, JP5, JP48 | Selects CGND or GND for antenna holder grounding. Default is CGND. |
| JP6 | JP6 allows you to select either the internal 5V regulator (INT PWR) or to choose EXT 5V (EXT PWR). For the EXT PWR, you can use your own external 5V power source and plug it into J11. |
| JP43, JP44 | Not used by PCIe devices. |
| JP45 | Board Power. Default is installed. |
| JP49 | Probes for connecting speaker. |
| JP50 | Probes for connecting microphone. |
| JP51, JP52 | Debugging probes for PCIe connector J23. |
| JP53, JP54 | Selects USB host connected to PCIe device. Pins 1 & 2 jumpered selects external USB host connected to J4. |
| JP57, JP58 | Selects USB host connected to quad serial UART U20. Pins 1 & 2 jumpered selects external USB host connected to J24. |
| JP59, JP60, JP61, JP63, JP64, JP69 | Selects serial connection for PCIe device. Pins 1 & 2 jumpered selects DB9 connector J1 connected to PCIe device. Pins 2 & 3 jumpered selects quad UART U20 connected to PCIe device. All jumpers must be moved to the same position. |
| JP65, JP66, JP67, JP68 | Selects serial connection for PCIe Bluetooth device. Pins 1 & 2 jumpered selects DB9 connector J14 connected to PCIe Bluetooth device. Pins 2 & 3 jumpered selects quad UART U20 connected to PCIe Bluetooth device. All jumpers must be moved to the same position. |
| JP70 | Probes for PCIe GPIO2 & GPIO3. The pin next to the text "GPIO_3.3V" is GPIO3. The center pin is GPIO2. |
| JP73, JP74 | Not used by PCIe devices. |
| JP75, JP76, JP77, JP78 | When these jumpers are installed, DVI interface of audio codec U84 is connected to DVI interface of PCIe device. By removing these jumpers when connecting an external DVI device. |
| JP79, JP80 | Use these jumper pins to connect an external DVI device. |
| JP81, J82 | Selects source for programming audio codec U84. Pins 1 & 2 jumpered selects MICRO U84 as source. Default is MICRO. |
| JP83, JP84 | These pins can be used for programming MICRO U84. |
| JP85 | Selects power source for MICRO U85. Default is 1.8v |
| JP86 | May be used to manually reset PCIe Bluetooth device by briefly installing and then removing a jumper. Default is no jumper installed. |
| JP87 | Not applicable for this device. |
| JP88 | May be used to manually reset PCIe Wi-Fi device by briefly installing and then removing a jumper. Default is no jumper installed. |
| JP89 | This jumper, when installed, connects power to PCIe device. |

| Jumper | Description |
|------------------|--|
| JP90 | Not used by PCIe device. This jumper, when installed, connects power to OCG-E device. (When using Developer Kit with OCG-E devices). |
| J6 | Not used by PCIe device. |
| J23 | Socket for installing PCIe device. |
| J8, J9, J10, J13 | Oscilloscope probe ground connections |
| S1 | Not used by PCIe device. |
| S3 | Reset button for PCIe device. |
| S4 | Button for on/off of PCIe. |

Installing a Communications Device onto the Board

To install a device on the board:

1. Align the device pin with Pin 1 of the socket connector on the board and press firmly.
2. Use the optional antenna lead to connect to the device's antenna connector.

Installing a SIM Card onto the Board

To install a SIM card:

- Install the SIM card into the SIM card holder on the radio.

Making Other Board Connections

Other connections you may need:

- If your application needs a power supply, connect the power supply lead to the power connector on the developer board.
- If you need to connect the debug cable for your application, connect the D89 male connector of the RS-232 cable to the D89 debug jumper next to the power switch.

Safety Notices and Warnings

The following safety statements may be relevant and required in the host product literature.

Radio Frequency (RF) Safety

Due to the possibility of radio frequency (RF) interference, it is important that you follow any special regulations regarding the use of radio equipment. Follow the safety advice given below.

- Operating your device close to other electronic equipment may cause interference if the equipment is inadequately protected. Observe any warning signs and manufacturers' recommendations.
- Different industries and businesses restrict the use of cellular devices. Respect restrictions on the use of radio equipment in fuel depots, chemical plants, or where blasting operations are in process. Follow restrictions for any environment where you operate the device.
- Do not place the antenna outdoors.
- Switch OFF your wireless device when in an aircraft. Using portable electronic devices in an aircraft may endanger aircraft operation, disrupt the cellular network, and is illegal. Failing to observe this restriction may lead to suspension or denial of cellular services to the offender, legal action, or both.
- Switch OFF your wireless device when around gasoline or diesel-fuel pumps and before filling your vehicle with fuel.
- Switch OFF your wireless device in hospitals and any other place where medical equipment may be in use.

Vehicle Safety

When using your device in a vehicle:

- Do not use this device while driving.
- Respect national regulations on the use of cellular devices in vehicles.
- If incorrectly installed in a vehicle, operating the wireless device could interfere with the vehicle's electronics. To avoid such problems, use qualified personnel to install the device. The installer should verify the vehicle electronics are protected from interference.
- Using an alert device to operate a vehicle's lights or horn is not permitted on public roads.
- UL evaluated this device for use in ordinary locations only. UL did NOT evaluate this device for installation in a vehicle or other outdoor locations. UL Certification does not apply or extend to use vehicles or outdoor applications or in ambient temperatures above 40° C.

User Responsibility

Respect all local regulations for operating your wireless device. Use the security features to block unauthorized use and theft.

Device Maintenance

When maintaining your device:

- Do not attempt to disassemble the device. There are no user serviceable parts inside.
- Do not expose your device to any extreme environment where the temperature or humidity is high.

- Do not expose the device to water, rain, or spilled beverages. It is not waterproof.
- Do not place the device alongside computer discs, credit or travel cards, or other magnetic media. The information contained on discs or cards may be affected by the device.
- Using accessories, such as antennas, that Multi-Tech has not authorized or that are not compliant with Multi-Tech's accessory specifications may invalidate the warranty.

If the device is not working properly, contact Multi-Tech Technical Support.

Labeling Requirements

Approvals and Certification

Your Multi-Tech device is an industry and/or carrier approved modem. In most cases, when integrated and used with an antenna system that was part of the Multi-Tech modem certification, additional approvals or certifications are not required for the device you develop as long as the following are met.

- **PTCRB Requirements (GPRS and HSPA/HSDPA only).**

The antenna system cannot be altered.

- **Model Identification**

The Multi-Tech model identification allows the carrier to verify the modem as one of its approved models. This information is located on the modem's label.

Note: Both the host device and modem include labels. When the cellular carrier asks you to provide the modem's model identification, give the Multi-Tech cellular model identification, not the host device model. The ESN or IMEI number on the host device label will match that of the modem.

- **For HSPA+, HSPA, HSDPA and GPRS Devices**

The modem's 15-character IMEI (International Mobile Equipment Identity) number is printed on the modem's label.

Example HSPA+ H5 Label

Note: Actual labels will vary depending on the regulatory approval markings and content.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The label shown is larger than actual size.

1 —> **Model: MTPCIE – H5 – V – BW**

2 —> **ORDER P/N: MTPCIE – H5 – V – BW**

SKU #: 92503309LF DOM: 2013.07.23

Serial#: XXXXXXXX

FCC ID: AU792U12616836

IC: 125A – 0048

FC Home or Office Use



- 1 - Multi-Tech Model Identification.
- 2 - Multi-Tech Ordering Part Number.
- 3 - IMEI (International Mobile Equipment Identity).

C US E150299



NODE ID: XX:XX:XX:XX:XX:XX

3 —> **IMEI: XXXXXXXXXXXXXXXX**

Produced in the US of US and non-US components
www.multitech.com

Regulatory Statements

R&TTE Directive Compliance

CE 0682

The CE mark is affixed to this product to confirm compliance with the following European Community Directives:

Council Directive 2004/108/EC of 15 December 2004 on the approximation of the laws of Member States relating to electromagnetic compatibility;

and

Council Directive 2006/95/EC of 12 December 2006 on the harmonization of the laws of Member States relating to electrical equipment designed for use within certain voltage limits;

and

Council Directive 1999/5/EC of 9 March 1999 on radio equipment and telecommunications terminal equipment and the mutual recognition of their conformity.

| | |
|-----------------------------------|--|
| RF spectrum use (R&TTE art. 3.2) | EN 301 511 V9.0.2 EN 300 440-2 V1.4.1 |
| EMC (R&TTE art. 3.1b) | EN 301 489-1 V1.9.2 EN 301 489-3 V1.4.1 EN 301 489-7 V1.3.1 |
| Health & Safety (R&TTE art. 3.1a) | EN 60950-1:2006 + A11:2009 + A1:2010 + A12:2011 + AC:2011 EN 62311:2008 |

Restriction of the Use of Hazardous Substances (RoHS)



Multi-Tech Systems, Inc

Certificate of Compliance

2011/65/EU

Multi-Tech Systems confirms that its embedded products comply with the chemical concentration limitations set forth in the directive 2011/65/EU of the European Parliament (Restriction of the use of certain Hazardous Substances in electrical and electronic equipment - RoHS).

These Multi-Tech products do not contain the following banned chemicals¹:

- Lead, [Pb] < 1000 PPM
- Mercury, [Hg] < 1000 PPM
- Hexavalent Chromium, [Cr+6] < 1000 PPM
- Cadmium, [Cd] < 100 PPM
- Polybrominated Biphenyl, [PBB] < 1000 PPM
- Polybrominated Diphenyl Ether, [PBDE] < 1000 PPM

Environmental considerations:

- Moisture Sensitivity Level (MSL) =1
- Maximum Soldering temperature = 260C (in SMT reflow oven)

¹Lead usage in some components is exempted by the following RoHS annex, therefore higher lead concentration would be found in some modules (>1000 PPM);

- Resistors containing lead in a glass or ceramic matrix compound.

International Modem Restrictions

Some dialing and answering defaults and restrictions may vary for international modems. Changing settings may cause a modem to become non-compliant with national regulatory requirements in specific countries. Also note that some software packages may have features or lack restrictions that may cause the modem to become non-compliant.

Other Countries

The above country-specific examples do not cover all countries with specific regulations; they are included to show you how each country may differ. If you have trouble determining your own country's requirements, check with Multi-Tech's Technical Support for assistance.

Environmental Notices

Waste Electrical and Electronic Equipment Statement

Note: This statement may be used in documentation for your final product applications.

WEEE Directive

The WEEE Directive places an obligation on EU-based manufacturers, distributors, retailers, and importers to take-back electronics products at the end of their useful life. A sister directive, ROHS (Restriction of Hazardous Substances) complements the WEEE Directive by banning the presence of specific hazardous substances in the products at the design phase. The WEEE Directive covers all Multi-Tech products imported into the EU as of August 13, 2005. EU-based manufacturers, distributors, retailers and importers are obliged to finance the costs of recovery from municipal collection points, reuse, and recycling of specified percentages per the WEEE requirements.

Instructions for Disposal of WEEE by Users in the European Union

The symbol shown below is on the product or on its packaging, which indicates that this product must not be disposed of with other waste. Instead, it is the user's responsibility to dispose of their waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or where you purchased the product.

July, 2005



Information on HS/TS Substances According to Chinese Standards

In accordance with China's Administrative Measures on the Control of Pollution Caused by Electronic Information Products (EIP) # 39, also known as China RoHS, the following information is provided regarding the names and concentration levels of Toxic Substances (TS) or Hazardous Substances (HS) which may be contained in Multi-Tech Systems Inc. products relative to the EIP standards set by China's Ministry of Information Industry (MII).

Hazardous/Toxic Substance/Elements

| Name of the Component | Lead (PB) | Mercury (Hg) | Cadmium (CD) | Hexavalent Chromium (CR6+) | Polybrominated Biphenyl (PBB) | Polybrominated Diphenyl Ether (PBDE) |
|----------------------------------|-----------|--------------|--------------|----------------------------|-------------------------------|--------------------------------------|
| Printed Circuit Boards | O | O | O | O | O | O |
| Resistors | X | O | O | O | O | O |
| Capacitors | X | O | O | O | O | O |
| Ferrite Beads | O | O | O | O | O | O |
| Relays/Opticals | O | O | O | O | O | O |
| ICs | O | O | O | O | O | O |
| Diodes/ Transistors | O | O | O | O | O | O |
| Oscillators and Crystals | X | O | O | O | O | O |
| Regulator | O | O | O | O | O | O |
| Voltage Sensor | O | O | O | O | O | O |
| Transformer | O | O | O | O | O | O |
| Speaker | O | O | O | O | O | O |
| Connectors | O | O | O | O | O | O |
| LEDs | O | O | O | O | O | O |
| Screws, Nuts, and other Hardware | X | O | O | O | O | O |
| AC-DC Power Supplies | O | O | O | O | O | O |
| Software /Documentation CDs | O | O | O | O | O | O |
| Booklets and Paperwork | O | O | O | O | O | O |
| Chassis | O | O | O | O | O | O |

X Represents that the concentration of such hazardous/toxic substance in all the units of homogeneous material of such component is higher than the SJ/Txxx-2006 Requirements for Concentration Limits.

O Represents that no such substances are used or that the concentration is within the aforementioned limits.

Information on HS/TS Substances According to Chinese Standards (in Chinese)

依照中国标准的有毒有害物质信息

根据中华人民共和国信息产业部 (MII) 制定的电子信息产品 (EIP) 标准—中华人民共和国《电子信息产品污染控制管理办法》(第 39 号), 也称作中国 RoHS, 下表列出了 Multi-Tech Systems, Inc. 产品中可能含有的有毒物质 (TS) 或有害物质 (HS) 的名称及含量水平方面的信息。

有害/有毒物质/元素

| 成分名称 | 铅 (PB) | 汞 (Hg) | 镉 (CD) | 六价铬 (CR6+) | 多溴联苯 (PBB) | 多溴二苯醚 (PBDE) |
|--------------|--------|--------|--------|------------|------------|--------------|
| 印刷电路板 | O | O | O | O | O | O |
| 电阻器 | X | O | O | O | O | O |
| 电容器 | X | O | O | O | O | O |
| 铁氧体磁环 | O | O | O | O | O | O |
| 继电器/光学部件 | O | O | O | O | O | O |
| ICs | O | O | O | O | O | O |
| 二极管/晶体管 | O | O | O | O | O | O |
| 振荡器和晶振 | X | O | O | O | O | O |
| 调节器 | O | O | O | O | O | O |
| 电压传感器 | O | O | O | O | O | O |
| 变压器 | O | O | O | O | O | O |
| 扬声器 | O | O | O | O | O | O |
| 连接器 | O | O | O | O | O | O |
| LEDs | O | O | O | O | O | O |
| 螺丝、螺母以及其它五金件 | X | O | O | O | O | O |
| 交流-直流电源 | O | O | O | O | O | O |
| 软件/文档 CD | O | O | O | O | O | O |
| 手册和纸页 | O | O | O | O | O | O |
| 底盘 | O | O | O | O | O | O |

X 表示所有使用类似材料的设备中有害/有毒物质的含量水平高于 SJ/Txxx-2006 限量要求。

O 表示不含该物质或者该物质的含量水平在上述限量要求之内。

Antennas, Cables, GPS

Antenna System Cellular Devices

The cellular/wireless performance is dependent on the implementation and antenna design. The integration of the antenna system into the product is a critical part of the design process; therefore, it is essential to consider it early so the performance is not compromised. If changes are made to the device's certified antenna system, then recertification will be required by specific network carriers.

PTCRB Antenna Requirements

There cannot be any alteration to the authorized antenna system. The antenna system must maintain the same specifications. The antenna must be the same type, with similar in-band and out-of-band radiation patterns.

This device has been designed to operate with the antennas listed below and having a maximum gain for 850 Mhz of ≤ 6.95 dBi, for 1700 Mhz of ≤ 6.5 dBi, and for 1900 Mhz of ≤ 3 dBi. Antennas not included in this list or that have a gain greater than specified are strictly prohibited for use with this device. The required antenna impedance is 50 ohms.

HSPA+/ UMTS Antenna Information

HSPA+/UTMS Authorized Antennas

HSPA+ devices were approved with the following antenna:

Manufacturer: Laird Technologies.
Model Number: HEPTA-SM MAF94300

Multi-Tech ordering information:

| Model | Quantity |
|------------|----------|
| ANHB-1HRA | 1 |
| ANHB-10HRA | 10 |
| ANHB-50HRA | 50 |

HSPA+ / UMTS Antenna Requirements/Specifications

| Category | Description | |
|-----------------------|---|------|
| Frequency Range | 824 – 960 MHz / 1710 – 1990 MHz / 1920 – 2170 MHz | |
| Impedance | 50 Ohms | |
| VSWR | VSWR should not exceed 2.0:1 at any point across the bands of operation | |
| Typical Radiated Gain | 850 dBi | 3.17 |
| | 950 dBi | 3.51 |
| | 1800 dBi | 3.55 |
| | 1900 dBi | 3.0 |
| | 2100 dBi | 3.93 |

| Category | Description |
|--------------|------------------|
| Radiation | Omni-directional |
| Polarization | Linear Vertical |

GPS Antennas

GPS Antenna Specifications

| Category | Description |
|-------------------------|-------------|
| Frequency Range | 1575.24 MHz |
| Impedance | 50 Ohms |
| VSWR | 2.0:1 max |
| Gain | 10-30 dBi |
| LNA Current Consumption | 40 mA max |
| Noise Figure | < 2dB |
| Polarization | RHCP |
| Input voltage | 3.0V ± 0.2V |

Bluetooth Antenna Specifications

| Category | Description |
|-----------------------|------------------|
| Frequency Range | 2402 to 2480 MHz |
| Impedance | 50 Ohms |
| VSWR | 2.0:1 max |
| Typical Radiated Gain | 2 dBi |
| Radiation | Omni-directional |

Wi-Fi Antennas

Manufacturer: Taoglas Antenna Solutions

Manufacturer's Model Number: GW.11.A153

Multi-Tech ordering information:

| Model Number | Quantity |
|--------------|----------|
| ANWF-1HRA | 1 |
| ANWF-10HRA | 10 |
| ANWF-50HRA | 50 |

Wi-Fi Antenna Specifications

| Category | Description |
|--------------------|---|
| Frequency Range | 2.4000 to 2.4835 GHz |
| Impedance | 50 Ohms |
| VSWR | VSWR should not exceed 2.0:1 at any point across the bands of operation |
| Peak Radiated Gain | 2.3 dBi on azimuth plane |
| Radiation | Omni-directional |
| Polarization | Linear Vertical |
| Connector | RP-SMA(M) |

Device Overview

Description

The MultiConnect PCIe embedded cellular modem is a complete, ready-to-integrate communications device that offers standards-based penta-band HSPA+ 21 performance. This quick-to-market communications device allows developers to add wireless communication and GPS tracking to products with a minimum of development time and expense. The MultiConnect PCIe embedded cellular modem is based on industry-standard open interfaces and uses a PCI Express Mini Card form factor.

Product Build Options

| Product | Description | Region |
|----------------------|--|------------------|
| MTPCIE-H5-V-BW-EU | HSPA+ Embedded Cellular Modem with digital voice, GPS, Wi-Fi and Bluetooth | Europe/GB |
| MTPCIE-H5-EU | HSPA+ Embedded Cellular Modem | Europe/GB |
| MTPCIE-BW | Wi-Fi and Bluetooth | US/Canada/Europe |
| Developer Kit | | |
| MTPCIE-DK | Developer Kit | Global |

Note:

- These units ship without network activation.
- To connect them to the cellular network, you need a cellular account. For more information, refer to Account Activation.
- GP devices have a dedicated GPS receiver.
- The complete product code may end in .Rx. For example, MTPCIE-H5.Rx, where R is revision and x is the revision number.
- All builds can be ordered individually or in 50-packs.

Account Activation for Cellular Devices

Some Multi-Tech cellular modems are pre-configured to operate on a specific cellular network, such as Sprint or Verizon Wireless. Before you can use the modem, you must set up a cellular data account with your service provider. Each service provider has its own process for adding devices to their network. Refer to Multi-Tech's Cellular Activation site <http://www.multitech.com/activation.go> for step-by-step instructions on activating your cellular modem with your service provider.

Bluetooth/Wi-Fi



All Wi-Fi and Bluetooth drivers and stacks are based on Linux open source.

- For Wi-Fi, use the Linux calibrator tool. The WiFi drivers are compat-wireless drivers for TI WL12XX build under Linux kernel 2.6.39.4. For more information see <http://linuxwireless.org/en/users/Drivers/wl12xx/calibrator>.
- For BlueTooth, use the Linux hcitool.

Both tools are currently available inside our embedded Linux systems. These tools do not run on PCs. To invoke the tools, secure shell into the device using putty or another tool from your Windows computer. Once you secure shell and login, you can invoke the tools and test. You will need Ethernet connectivity to the development board for the secure shell and login.

Mechanical Drawing



MTPCIE-H5-xx



MTPCIE-H5-xx

DIMENSION IN INCHES [mm]

MTPCIE-BW



MTPCIE-BW

DIMENSION IN INCHES [mm]

Specifications

MTPCIE-H5 Specifications

| Category | Description |
|------------------------------|--|
| General | |
| Standards | Penta-band HSPA+ 21 |
| | Quad-band GSM/GPRS/EDGE |
| | SMS is based on CS/Packet-Switched (PS) domain of GSM and WCDMA |
| | USB Interface is CDC-ACM compliant |
| Frequency Bands | Penta-band HSPA: 850/900/1700/1900/2100 MHz |
| | Quad-band GSM/GPRS/EDGE: 850/900/1800/1900 MHz |
| Speed | |
| Data Speed | HSDPA data service of up to 21.0 Mbps downlink/5.76 Mbps uplink |
| Interface | |
| USB Interface | USB 2.0 high speed compatible |
| UART Interface | 0-1.8V |
| Physical Description | |
| Weight | 0.4 oz. (10 g) |
| Dimensions | 1.892" x 1.181" (48.057 mm x 29.997 mm) Note: With the form factor, dimensions exceed the standard MiniPCIe maximum component height for top and bottom. Consult the Design Consideration chapter in the MultiConnect PCIe Developer Guide for more information. |
| Connectors | |
| Antenna Connector | 2 surface mount UFL: cellular, GPS |
| | Bluetooth and Wi-Fi: share 1 UFL connector |
| SIM Holder | Standard 1.8V and 3V |
| Environment | |
| Operating Temperature | -35° C to +85° C |
| Storage Temperature | -35° C to +85° C |
| Humidity | 20%-90% RH, non-condensing |
| Power Requirements | |
| Operating Voltage | |
| Input Power | 3.3VDC |
| SMS, Wi-Fi, Bluetooth | |

| Category | Description |
|--------------------------------------|--|
| SMS | Point-to-Point messaging |
| | Mobile-Terminated SMS |
| | Mobile-Originated SMS |
| Wi-Fi | IEEE 802.11 b,g, n, compliant |
| | SDIO host interface (0-1.8V) |
| Bluetooth | V4 with Bluetooth Low Energy (BLE), Power Class 1.5 |
| | Serial Port Protocol (SPP) |
| | UART Interface 1.8V |
| GPS | High-sensitivity of indoor reception, better than -165 |
| | Cold start autonomous -147 dBm |
| | Hot start autonomous -161 dBm |
| | Tracking mode -166 dBm |
| | Accuracy 3 m |
| | TTF from cold start 42 s |
| | TTF from warm start 30 s |
| | TTF from hot start 1.8 s |
| | Multi-channel GPS |
| | L1 1575.42 MHz |
| | GPS NMEA 0183 output format |
| Datum WGS-84 | |
| Certifications and Compliance | |
| EMC Compliance | FCC Part 15 Class B |
| | EN55022 Class B |
| | EN55024 |

| Category | Description |
|--------------------|---|
| Radio Compliance | FCC Part 22 |
| | FCC Part 24 |
| | FCC Part 15C (BT & Wi-Fi intentional radiators) |
| | RSS 132 |
| | RSS 133 |
| | Part 27 resp. RSS-139 |
| | EN 301 511 |
| | EN 301 489-1 |
| | EN 301 489-7 |
| | EN 301 489-24 |
| Safety Compliance | UL 60950-1 |
| | cUL 60950-16t |
| | EN 60950-1 |
| Network Compliance | GCF Certified Module |

MTPCIE-H5 DC Electrical Characteristics

Units: Volts

| Parameter | Minimum | Maximum |
|-------------------|---------|---------|
| 3.3 Volt Powered | 3.0 | 3.6 |
| Input Low Level | 0 | 0.35 |
| Input High Level | 1.5 | 1.9 |
| Output Low Level | 0 | 0.2 |
| Output High Level | 1.6 | 1.9 |

Absolute Maximum Rating

Voltage at any signal pin: 0.0V to +1.9V

PCIe Connector Leads

| PIN # | Name | I/O | Function | Type | Notes | MTPCIE-H5-V-BW | MTPCIE-H5 | MTPCIE-H5-V |
|-------|----------|-----|--------------------------------|------|--|----------------|-------------|-------------|
| 1 | SDIO_D0 | I/O | Wi-Fi SDIO_D0 | 1.8V | SDIO can operate up to 25Mhz. The SDIO traces to Host must be treated like a bus and the bus length shall be as short as possible. Recommend adding series termination resistors on all the SDIO traces. | | no function | no function |
| 2 | 3.3Vaux | I | 3.3Vaux | | | | | |
| 3 | SDIO_D1 | I/O | Wi-Fi SDIO_D1 | 1.8V | | | no function | no function |
| 4 | GND | | Ground | | | | | |
| 5 | SDIO_D2 | I/O | Wi-Fi SDIO_D2 | 1.8V | | | no function | no function |
| 6 | BT_TXD | I | Bluetooth Transmit data | 1.8V | | | no function | no function |
| 7 | SDIO_D3 | I/O | Wi-Fi SDIO_D3 | 1.8V | | | no function | no function |
| 8 | BT_RTS | I | Bluetooth RTS | 1.8V | | | no function | no function |
| 9 | GND | | Ground | | | | | |
| 10 | BT_CTS | O | Bluetooth CTS | 1.8V | | | no function | no function |
| 11 | SDIO_CMD | I/O | Wi-Fi SDIO_CMD | 1.8V | | | no function | no function |
| 12 | BT_RXD | O | Bluetooth Receive data | 1.8V | | | no function | no function |
| 13 | SDIO_CLK | I | Wi-Fi SDIO_CLK | 1.8V | Upto 25mhz | | no function | no function |
| 14 | BT_EN | I | Bluetooth enable (low disable) | 1.8V | low disable | | no function | no function |
| 15 | GND | | Ground | | | | | |


| PIN # | Name | I/O | Function | Type | Notes | MTPCIE-H5-V-BW | MTPCIE-H5 | MTPCIE-H5-V |
|-------|----------|-----|---------------------------------------|------|--|----------------|----------------|----------------|
| 16 | GPIO_2 | I/O | 3G Cellular General purpose I/O | 1.8V | AT#GPIO=2,x,x | | no function | |
| 17 | WLAN_EN | I | Wi-Fi enable (low disable) | 1.8V | Low disable | | no function | no function |
| 18 | GND | | Ground | | | | | |
| 19 | WLAN_IRQ | O | Wi-Fi interrupt (low active) | 1.8V | Low active | | no function | no function |
| 20 | 3G_ONOFF | I | 3G Cellular On/Off (low active) | 1.8V | Active Low: Properly turn off and detach from the carrier network. Initial power on needs at least 5.5 seconds before AT command are issued. Low for at least 1 second turns off the 3G radio. It can take at least 8 seconds to turn off 3G radio. High turns on the 3G radio and it needs at least 13 seconds before AT commanda are issued.. No connect if not used. | | | |
| 21 | GND | | Ground | | | | | |

| PIN # | Name | I/O | Function | Type | Notes | MTPCIE-H5-V-BW | MTPCIE-H5 | MTPCIE-H5-V |
|-------|------------|-----|--|------------------------------|---|----------------|-------------|-------------|
| 22 | 3G_RST | I | 3G Cellular Reset line (low active) | 1.8V | Active Low: Emergency reset without proper shutdown and without detach from the network. Low for at least 50 ms resets the 3G radio. It takes at least 2.5 seconds to reset and turn the 3G radio off. High turns on the 3G radio and needs at least 7.5 seconds before AT command are issued. No connect if not used | | | |
| 23 | 1.8V | O | 1.8V output | 100mA output current at 1.8V | | | no function | no function |
| 24 | 3.3Vaux | I | 3.3Vaux | | | | | |
| 25 | GPIO_1 | I/O | Bluetooth General purpose I/O | 1.8V | No connect | | no function | no function |
| 26 | GND | | Ground | | | | | |
| 27 | GND | | Ground | | | | | |
| 28 | 3G_DVI_WA0 | I/O | 3G Cellular digital voice control line | 1.8V | | | no function | |
| 29 | GND | | Ground | | | | | |
| 30 | 3G_DVI_CLK | I/O | 3G Cellular digital voice clock | 1.8V | | | no function | |
| 31 | 3G_DVI_RX | I | 3G Cellular digital voice receive | 1.8V | | | no function | |
| 32 | RI | O | 3G Cellular UART RI | 1.8V | | | no function | |

| PIN # | Name | I/O | Function | Type | Notes | MTPCIE-H5-V-BW | MTPCIE-H5 | MTPCIE-H5-V |
|-------|------------|-----|------------------------------------|------|--|----------------|-------------|-------------|
| 33 | 3G_DVI_TX | O | 3G Cellular digital voice transmit | 1.8V | | | no function | |
| 34 | GND | | Ground | | | | | |
| 35 | GND | | Ground | | | | | |
| 36 | USB_D- | I/O | 3G USB Negative Data | 3.3V | | | | |
| 37 | GND | | Ground | | | | | |
| 38 | USB_D+ | I/O | 3G USB Positive Data | 3.3V | | | | |
| 39 | 3.3Vaux | I | 3.3Vaux | | | | | |
| 40 | GND | | Ground | | | | | |
| 41 | 3.3Vaux | I | 3.3Vaux | | | | | |
| 42 | LED_WWA N# | O | 3G Cellular STAT LED Output | 1.8V | <p>Command to enable LED function, AT#GPIO=1,0,2. This pin needs an external transistor to drive an external LED. Therefore, status indicated is reversed with respect to the pin status:</p> <p>Permanently off = Device off</p> <p>Fast blinking (Period 1s, Ton 0.5s) = Net search / Not registered / turning off</p> <p>Slow blinking (Period 3s, Ton 0.3s) = Registered full service</p> <p>Permanently on = a voice call is active</p> | | | |
| 43 | GND | | Ground | | | | | |

| PIN # | Name | I/O | Function | Type | Notes | MTPCIE-H5-V-BW | MTPCIE-H5 | MTPCIE-H5-V |
|-------|---------|-----|---------------------------------|------|---|----------------|-------------|-------------|
| 44 | DCD | O | 3G Cellular UART DCD | 1.8V | | | no function | |
| 45 | CTS | O | 3G Cellular UART CTS | 1.8V | | | no function | |
| 46 | GPIO_3 | I/O | 3G Cellular General purpose I/O | 1.8V | AT#GPIO=3,x,x | | no function | |
| 47 | RTS | I | 3G Cellular UART RTS | 1.8V | Avoid having any HIGH logic level signal applied to any 3G input digital pins when the 3G module is powered off or during an ON/OFF transition. | | no function | |
| 48 | DTR | I | 3G Cellular UART DTR | 1.8V | Avoid having any HIGH logic level signal applied to any 3G input digital pins when the 3G module is powered off or during an ON/OFF transition. | | no function | |
| 49 | RXD | O | 3G Cellular UART Receive data | 1.8V | | | no function | |
| 50 | GND | | Ground | | | | | |
| 51 | TXD | I | 3G Cellular UART transmit data | 1.8V | Avoid having any HIGH logic level signal applied to any 3G input digital pins when the 3G module is powered off or during an ON/OFF transition. | | no function | |
| 52 | 3.3Vaux | I | 3.3Vaux | | | | | |

Typical Power Flow



- Peak inrush current is a fast rising pulse at power start up on board supplies or modem cap charging. It is influenced by the design and limits of the power supply providing power to the device.
- Radio initialization is a lower value steady current phase that occurs while the radio gets initialized and ready to talk to the cell network.
- Once connected to the network, there is a steady idle current state.
- When data is transmitted to the network, power peaks from this idle state. Peak data values are influenced by the distance from the towers and decided by the carrier network.
- Power starts dropping when the device is disconnected.
- After it is disconnected, power draw lowers if the device is told to enter sleep mode. Sleep mode keeps the receiver active and the device periodically wakes up long enough to tell the network it is still available.

Power Measurements

Multi-Tech Systems, Inc. recommends that you incorporate a 10% buffer into your power source when determining product load.

MTPCIE-H5

| Radio Protocol | Cellular Call Box Connection No Data (Amps) | Average Measured Current (Amps) at Maximum Power | TX Pulse (Avg) Amplitude Current (Amps) for GSM850 or Peak Current for HSDPA | Total Inrush Charge Measured in Millicoulomb |
|------------------|---|--|--|--|
| 3.3 Volts | | | | |
| GSM850 | 0.056 | 0.629 | 2.5 | 5.27 |
| HSDPA | 0.057 | 0.727 | 0.804 | 5.27 |

Note: Inrush Current:The input current during power up, or a reset.

MTPCIE-H5-V-BW

| Radio Protocol | Cellular Call Box Connection No Data (Amps) | Average Measured Current (Amps) at Maximum Power | TX Pulse (Avg) Amplitude Current (Amps) for GSM850 or Peak Current for HSDPA | Total Inrush Charge Measured in Millicoulomb |
|------------------|---|--|--|--|
| 3.3 Volts | | | | |
| GSM850 | 0.062 | 1.058 | 2.9 | 2.51 |
| HSDPA | 0.062 | 0.970 | 1.052 | 2.51 |

Note: Inrush Current:The input current during power up, or a reset.

MTPCIE-BW

| Voltage | Inrush Current (Amps) | Idle Mode after MT100EOCG Boots Up (Amps) | Max Power with Bluetooth and Wi-Fi in Broadcast Mode (Amps) |
|------------------|-----------------------|---|---|
| 3.3 Volts | 0.056 | 0.0064 | 0.326 |

Note: Inrush Current:The input current during power up, or a reset.

Device Configuration

Device Configuration Notes

```
# Country code (ISO/IEC 3166-1). Used to set regulatory domain.  
# Set as needed to indicate country in which device is operating.  
# This can limit available channels and transmit power.  
country_code=US
```

```
# Enable IEEE 802.11d. This advertises the country_code and the set of allowed # channels and transmit  
power levels based on the regulatory limits. The # country_code setting must be configured with the  
correct country  
for # IEEE 802.11d.functions.  
# (default: 0 = disabled)  
ieee80211d=1
```

Application Notes

RF Performances

RF performances are compliant with the ETSI recommendation 05.05 and 11.10. The module's radio transceiver meets the requirements of 3GPP Release 5 & 6. All values indicated are conducted.

Receiver Features for Cellular Devices

| Category | Description |
|-------------------------------|-------------|
| GSM 850 Sensitivity | < -109 dBm |
| E-GSM 900 Sensitivity | < -106 dBm |
| DCS 1800 Sensitivity | < -105 dBm |
| PCS 1900 Sensitivity | < -105 dBm |
| UMTS Band I 2100 Sensitivity | < -109 dBm |
| UMTS Band II 1900 Sensitivity | < -108 dBm |
| UMTS Band V 850 Sensitivity | < -110 dBm |
| UMTS Band VI 800 Sensitivity | < -110 dBm |

RF connection and antenna

The RF connector on the modem is a UFL standard type.

Note: For unlicensed transmitters in this device (Bluetooth, WiFi) only antennas as specified in this manual may be permanently connected / installed by the OEM, so that it can not be replaced by end-users without availability of special tools.

Frequency Bands

| Mode | Freq. TX (MHz) | Freq. RX (MHz) | Channels | TX-RX offset |
|----------------------|-----------------|-----------------|---|--------------|
| GSM850 | 824.2 - 848.8 | 869.2 - 893.8 | 128 - 251 | 45 MHz |
| EGSM900 | 890.0 - 914.8 | 935.0 - 959.8 | 0 - 124 | 45 MHz |
| | 880.2 - 889.8 | 925.2 - 934.8 | 975 - 1023 | 45 MHz |
| DCS1800 | 1710.2 - 1784.8 | 1805.2 - 1879.8 | 512 - 885 | 95 MHz |
| PCS1900 | 1850.2 - 1909.8 | 1930.2 - 1989.8 | 512 - 810 | 80 MHz |
| WCDMA850 (band V) | 826.4 - 846.6 | 871.4 - 891.6 | Tx: 4132 - 4233 Rx: 4357 - 4458 | 45 MHz |
| WCDMA900 (band VIII) | 882.4 - 912.6 | 927.4 - 957.6 | Tx: 2712 - 2863 Rx: 2937 - 3088 | 45 MHz |
| WCDMA1700 (band IV) | 1710.4 - 1755.6 | 2112.4 - 2167.6 | Tx: 1312 - 1513 Rx: 9662 - 9938 | 400MHz |
| WCDMA1900 (band II) | 1852.4 - 1907.6 | 1932.4 - 1987.6 | Tx: 9262 - 9538 Rx: 9662 - 9938 | 80MHz |
| WCDMA2100 (band I) | 1922.4 - 1977.6 | 2112.4 - 2167.6 | Tx: 9612 - 9888 Rx: 10562 - 10838 | 190MHz |

Installing Drivers for Non-UIP HSPA+ Devices

HSPA+ Device Driver Installation

Installing on Linux

The Linux OS includes a generic USB driver for modems supporting CDC/ACM.

Multi-Tech tested the following Linux operating systems and all used port ttyACM0. If your system has another device using this port, your port numbers may be different.

- Ubuntu 13.04
- Debian 6.0.6
- Fedora 15
- openSUSE 11.4
- CentOS 6.0

To install the device on any Linux Kernel with CDC/ACM support, connect USB cable from the device to a USB port on your computer. For most recent Linux distributions, there are no drivers to install.

If the operating system recognizes the modem, seven devices are created (assuming no other ACM values have been assigned):

- /dev/ttyACM0
- /dev/ttyACM1
- /dev/ttyACM2
- /dev/ttyACM3
- /dev/ttyACM4
- /dev/ttyACM5
- /dev/ttyACM6

Only the following devices can be used for AT commands:

- /dev/ttyACM0 (data port for PPP connections and AT commands)
- /dev/ttyACM3 (generic port for AT commands)

Troubleshooting Linux

If Linux does not create devices, check for the kernel module:

```
# lsmod | grep cdc_acm
```

If entries aren't found, load the kernel module with root privileges:

```
# modprobe cdc-acm
```

If this returns an error response, such as # FATAL: Module cdc-acm not found, the kernel module is not on your system. You will need to build the driver.

Building a Linux Driver

If your system is missing the Linux driver:

1. Retrieve the appropriate kernel source code version for your system. This should be in your OS distribution package. Unpack it.
2. In its root directory type: **# make menuconfig**
3. Configure the kernel according to your system configuration,
4. Browse to menu **Device Driver > USB Support** and select **USB Modem (CDC ACM) support**.
5. To start the build once configured, type **# make**

The kernel module `cdc-acm.ko` is in the directory `drivers/usb/class`. If the kernel was built previously, compile the module by typing:

```
# make M=drivers/usb/class
```

To load the module use `modprobe` or `insmod`.

Windows Release Notes

We tested `h5-u_windriver_8.00.04.zip` `ev3-u_windriver_8.00.04.zip` driver on the following Windows operating systems.

- **Windows 8 x86 and x64, Windows 7 x86 and x64, Vista x86 and x64, XP x86 and x64, Windows Server 2012, Windows Server 2008 x86 and x64, and Windows Server 2003 x86**
 - Drivers install correctly, but may require .NET Framework version 3.5 or older.
 - After installing the driver for this device, the device may not be available when Windows comes out of a sleep/hibernate state. To correct this issue, unplug the device from the USB port and then plug it back in to the same port.
- **Windows Server 2003 x64**
 - Not supported with version 8.00.04.

Downloading the Windows USB Driver

If you haven't downloaded the driver:

1. Go to the Multi-Tech Support page, www.multitech.com/support.go and select your product from the Product Families drop down list.
2. Click **Drivers**.
3. Select **h5-u_windriver_8.00.04.zip** and **Save** the driver to your computer.
4. Extract the files to your computer.

Windows Notes

Installing on USB Host Powered Devices

When you connect a USB host powered device to a computer through a USB cable, the Windows **Add New Hardware Wizard** may display **Cannot Install this Hardware**. If this occurs, click **Finish**. Windows detects additional devices and prompts you to install them.

Installing on Non-USB Powered Devices

Turn on the device and wait 15 seconds before connecting the USB cable. If you connect the USB cable before supplying power to the device, the Windows **Add New Hardware Wizard** may appear and show **Cannot Install this Hardware**. If this occurs, click Finish. Windows detects additional devices and prompts you to install the additional devices. If Windows does not detect new device, unplug the USB cable, turn the device off and on, wait 15 seconds, insert the USB cable, and install devices when prompted.

Installing on Windows 8, 7 or Vista

This process installs multiple drivers and ports.

Note: If you previously installed USB drivers for this device, uninstall them before installing or re-installing this driver. Uninstall all existing drivers for this device. Refer to Uninstall Windows Drivers for details.

Before you connect the device (disconnect the device if you connected it):

CAUTION: If you connected the device before installing the drivers, Windows may install drivers automatically. Your device may not operate correctly with these drivers. Uninstall the drivers before proceeding. See Remove Microsoft Installed Drivers for details.

1. Go to the location where you extracted the driver and open the **H5-USB\Driver** folder.
2. Right-click on **TelitUSBInstaller_In_U8.00.04.exe** and select **Run as Administrator**.
3. Click **Yes** or **Allow** to allow the installer to make changes to your computer.
4. Click **Next** and follow the instructions in the installation wizard.
5. Click the **Install** option when prompted, for example, Install this driver software anyway.
6. Click **Finish**.
7. Connect USB cable from the device to a USB port on your computer. Windows indicates when the device is ready to use.
8. Signal strength LEDs require a device reboot after installing software. Disconnect the device from the computer's USB port for a few seconds and reconnect the device to the same USB port.

Installing on Windows XP

This process installs four drivers.

Note: If you previously installed USB drivers for this device, uninstall them before installing or re-installing this driver. Uninstall all existing drivers for this device. Refer to Uninstall Windows Drivers for details.

Before you connect the device (disconnect the device if you connected it):

1. Go to the location where you extracted the driver and open the **H5-USB\Driver** folder.
2. Right-click on **TelitUSBInstaller_In_U8.00.04.exe** and select **Run**.
3. Click **Next** and follow the instructions in the installation wizard.
4. Click **Continue Anyway** each time this screen appears.



5. Click **Finish**.
6. Connect USB cable from the device to a USB port on your computer. After it detects the hardware, Windows opens the New Hardware Wizard.
7. Select **No, not this time** and click **Next**.
8. Select **Install the software automatically (Recommended)** and click **Next**.
9. Select **Finish**.
10. Repeat Steps 7-9 for each additional New Hardware Wizard. Windows indicates when the device is ready to use.
11. Signal strength LEDs require a device reboot after installing software. Disconnect the device from the computer's USB port for a few seconds and reconnect the device to the same USB port.

Uninstalling Windows Drivers

Note: Disconnect the device before uninstalling drivers.

Windows 8

To uninstall drivers from Windows 8:

1. Open Windows **Programs and Features**.
2. Uninstall **Windows Driver Package – Intel Mobile Communications (flashusb) USB**.
3. Uninstall all **Telit modems, ports, and USB drivers**.

Windows 7 or Vista

To uninstall drivers from Windows 7 or Vista:

1. Open **Programs and Features** from the Windows Control Panel.
2. Uninstall the **Windows Driver Package – Telit Wireless Solutions (telitusbser) Modem**.
3. Uninstall all **Telit modems, ports, and USB**.

Windows XP


To uninstall drivers from Windows XP:

1. Open the **Control Panel** and go to **Add or Remove Programs**.
2. Uninstall **Windows Driver Package – Telit Wireless Solutions (telitusbser) Modem**.
3. Uninstall all other **Telit modems, Ports and USB**.

Remove Microsoft Installed Drivers

If using Windows 7 and connect the device before installing drivers, Windows Update automatically installs drivers. Your device may not operate correctly with these drivers. To remove these drivers:

1. With the device plugged in, open the **Device Manager**.



2. Right-click on the Telit Mobile Modem and select **Uninstall**.
3. Select **Delete the driver software for this device** and click **OK**.
4. Repeat the removal steps to uninstall each Telit port and the Telit Universal Serial Bus Control.

Developer Note

By default each time an H5 device with a different IMEI value is connected using this USB driver, the operating system will not require searching for the drivers again and uses the same ports created in a previous installation. To prevent this, use the utility included with the driver download to manage port creation as follows.

To enable USB IMEI identification, where the operating system creates a new set of ports with different COM enumeration for each H5 device with a different IMEI value:

1. Uninstall the driver if already installed.
2. Double-click **H5_enable_USB_IMEI_identification.reg** in the folder where you extracted the driver files.
3. Install the driver as normal.

To disable USB IMEI identification (driver default setting):

1. Uninstall the driver if already installed.
2. Double-click **H5_disable_USB_IMEI_identification.reg** in the folder where you extracted the driver files.
3. Install the driver as normal.

Using Linux with H5 Devices

Shell Commands

Testing Serial Ports

To test the serial ports created by the driver, type in a shell:

```
# cat /dev/ttyACM0 &
# echo -en "ATE0\r" > /dev/ttyACM03
# echo -en "AT\r" > /dev/ttyACM0
```

Note: Sending ATE0 is required, to avoid issues in the terminal output. It prevents the sending/receiving spurious characters to/from the modem when used with the Linux commands “echo” and “cat”

You can perform the same test using the other interface (ttyACM1 ttyACM3).

Create a PPP Connection

Most recent Linux distributions have GUI tools for creating PPP connections; the following instructions are for creating a PPP connection through command line interface.

PPP support must be compiled into the kernel; pppd and chat programs are also required.

pppd needs two scripts: the first script performs the environment setting and calls the second script, which is used by the chat program. For creating a PPP connection type:

```
# pppd file /etc/pppd_script &
```

Example

```
# Debug info from pppd
debug
#kdebug 4
# Most phones don't reply to LCP echos
lcp-echo-failure 3
lcp-echo-interval 3
# Keep pppd attached to the terminal
# Comment this to get daemon mode pppd
nodetach
# The chat script (be sure to edit that file, too!)
connect "/usr/sbin/chat -v -f /etc/chatscripts/hsdpa_connect"
# Serial Device to which the modem is connected
/dev/ttyACM3
# Serial port line speed
115200
dump
# The phone is not required to authenticate
#noauth
user <insert here the correct username for authentication>
name <insert here the name of the connection>
password <insert here the correct password for authentication>
```

```

# If you want to use the HSDPA link as your gateway
defaultroute
# pppd must not propose any IP address to the peer
#noipdefault
ipcp-accept-local
ipcp-accept-remote
# Keep modem up even if connection fails
#persist
# Hardware flow control
crtscts
# Ask the peer for up to 2 DNS server addresses
usepeerdns
# No ppp compression
novj
nobsdcomp
novjcomp
nopcomp
noaccomp
# For sanity, keep a lock on the serial line
lock
# Show password in debug messages
show-password

```

This script calls the option *connect* using the script *hsdpa_connect*, for example: `#!/bin/sh`

```

# Connection to the network
" AT+CGDCONT=1,"IP","<insert here the correct APN provided by
your network operator>"
# Dial the number.
OK ATD*99***1#
# The modem is waiting for the following answer
CONNECT "
After launching a PPP connection is possible to use ftp protocol or other utilities that allow the access to the
Internet.

```

C Programming

The following topics show all the functions that can be used from C source code to perform read/write operations on the serial devices.

`open()`

The *open()* function shall establish the connection between a file and a file descriptor. The file descriptor is used by other I/O functions to refer to that file.

Header File

`fcntl.h`

Prototype:

```
int open(const char *pathname, int flags)
```

Parameters:

pathname – file name with its own path.

flags – is an *int* specifying file opening mode: is one of O_RDONLY, O_WRONLY or O_RDWR which request opening the file read-only, write-only or read/write, respectively.

Returns:

The new file descriptor *filides* if successful, -1 otherwise.

Example

Open the `/dev/ttyACM0`.

```
int fd; // file descriptor for the /dev/ttyACM0 entry
if((fd = open("/dev/ttyACM0", O_RDONLY) < 0)
{
/* Error Management Routine */
} else {
/* ttyACM0 Device Opened */
}
```

read()

The `read()` function reads *nbyte* bytes from the file associated with the open file descriptor, *filides*, and copies them in the buffer that is pointed to by *buf*.

Header File

unistd.h

Prototype:

```
ssize_t read(int fildes, void *buf, size_t nbyte)
```

Parameters:

fildes - file descriptor

buf - destination buffer pointer

nbyte - number of bytes that read() attempts to read

Returns:

The number of bytes actually read if the operation is completed successfully, otherwise it is -1.

Example

Read `sizeof(read_buff)` bytes from the file associated with *fd* and stores them into *read_buff*.

```
char read_buff[BUFF_LEN];
if(read(fd, read_buff, sizeof(read_buff)) < 0)
{
/* Error Management Routine */
} else {
/* Value Read */
}
```

write()

The *write()* function writes *nbyte* bytes from the buffer that are pointed by *buf* to the file associated with the open file descriptor. *filides*.

Header File

unistd.h

Prototype:

```
ssize_t write(int fildes, const void *buf, size_t nbyte)
```

Parameters:

fildes – file descriptor

buf – destination buffer pointer

nbyte – number of bytes that *write()* attempts to write

Returns:

The number of bytes actually written if the operation is completed successfully, otherwise it is -1.

Example

Write *strlen(value_to_be_written)* bytes from the buffer pointed by *value_to_be_written* to the file associated with the open file descriptor, *fd*.

```
char value_to_be_written[] = "dummy_write";
if (write(fd, value_to_be_written, strlen(value_to_be_written)) < 0)
{
/* Error Management Routine */
} else {
/* Value Written */
}
```

close()

The *close()* function shall deallocate the file descriptor indicated by *fildes*. To deallocate means to make the file descriptor available for return by subsequent calls to *open()* or other functions that allocate file descriptors.

Header File

unistd.h

Prototype:

```
int close(int fildes);
```

Parameters:

fildes - file descriptor

Returns:

0 if successful, otherwise it is -1.

Example

Close the ttyACMx file.

```
if(close(fd) < 0)
{
/* Error Management Routine */
} else {
/* File Closed */
}
```

Test Program()

The following simple C program is useful to test the modem issuing an AT command. The program opens the /dev/ttyACM0 interface and calls the write() and the read() function to send an AT command and receive the subsequent output.

```
#include <stdio.h> /* Standard input/output definitions */
#include <string.h> /* String function definitions */
#include <unistd.h> /* UNIX standard function definitions */
#include <fcntl.h> /* File control definitions */
#include <errno.h> /* Error number definitions */
#include <termios.h> /* POSIX terminal control definitions */
#define USB "/dev/ttyACM0"
#define BUFSIZE 1000
#define BAUDRATE B115200
int open_port(char *port)
{
struct termios options;
int fd;
fd = open(port, O_RDWR | O_NOCTTY | O_NDELAY);
if (fd == -1)
{
printf("open_port: Unable to open the port - ");
}
else
{
printf ( "Port %s with file descriptor=%i",port, fd);
fcntl(fd, F_SETFL, FNDELAY);
tcgetattr( fd, &options );
cfsetispeed( &options, BAUDRATE );
cfsetospeed( &options, BAUDRATE );
options.c_cflag |= ( CLOCAL | CREAD);
options.c_cflag &= ~(CSIZE | PARENB | CSTOPB | CSIZE);
options.c_cflag |= CS8;
options.c_cflag &= ~CRTSCTS;
options.c_lflag &= ~(ICANON | ECHO | ECHOE | ISIG);
options.c_iflag &= ~(IXON | IXOFF | IXANY | ICRNL | INLCR |
IGNCR);
options.c_oflag &= ~OPOST;
if ( tcsetattr( fd, TCSANOW, &options ) == -1 )
printf ("Error with tcsetattr = %s\n", strerror ( errno )
);
}
```

```
else
printf ( "%s\n", "succeed" );
}
return (fd);
}
int main()
{
int serialFD = open_port(USB);
char buf[BUFSIZE];
memset(buf,0,BUFSIZE);
write(serialFD, "AT\r" , strlen("AT\r"));
sleep(1);
read( serialFD, buf, BUFSIZE );
printf("The string is: %s\n", buf);
close(serialFD);
return 0;
}
```

The sleep instruction is required because the modem response after issuing the AT command is not immediate, so you need to wait a bit before reading. There are more efficient ways to do this, for example, you can put the read call in a while loop and exit when the read buffer contains a certain string.

Bluetooth Developer Information

If using the MTPCIE Developer Kit with an MT100EOCG and an MTPCIE Bluetooth/Wi-Fi radio, Bluetooth developer content and sample code are available online at multitech.net.

The following models support Bluetooth/Wi-Fi functionality:

| Model | Description |
|----------------|----------------------------|
| MTPCIE-BW | Bluetooth/Wi-Fi only |
| MTPCIE-H5-V-BW | HSPA+ with Bluetooth/Wi-Fi |

Configuring the MTPCIE-DK1 Developer Board

To use the MTPCIE-DK1 developer board with an MT100EOCG and an MTPCIE Bluetooth/Wi-Fi device:

1. Position jumpers next to USB 3G connector J4 in the 2,3 position.
2. Install the radio and MT100EOCG on the MTPCIE-DK1 developer board and power up the board.
3. Connect the serial cable between the computer's serial port and the MT100EOCG debug DB9 connector.
4. Run terminal software on the computer with the serial port configured as: 115.2K Bits per second 8 Data bits None Parity 1 Stop bits None Flow control
5. Power up the MTPCIE-DK1. Linux boots up and the command prompt appears.
6. Enter **root** as the default user name and password.

Calibrating Wi-Fi and Programming the MAC Address

To calibrate the Wi-Fi and program the MAC address:

1. Attach Wi-Fi/Bluetooth antenna to the MTPCIE.
2. Run the following command on the device: **calibrate-wifi.sh <WIFI-MAC-ADDRESS>**

Creating a PPP Connection

For more information, go to www.multitech.net/developer/products/multiconnect-ocg/applications/ppp-peers.

1. Verify your wireless account is activated with a data plan. If using a GSM radio like MTPCIE-H5-BW, install the SIM card.
2. If using a GSM radio, edit **/etc/ppp/peers/gsm_chat** file and change the APN to match up with the SIM card
3. Connect the cellular antenna to the MTPCIE device.
4. In the MT100EOCG, enter:
For MTPCIE-H5 devices: **pppd call gsm**
5. After 10 seconds, enter **ip a** in the MT100EOCG to verify the PPP link is up and an IP address obtained.

Setting Wi-Fi Access Point with an MT100EOCG and an MTPCIE Bluetooth/Wi-Fi

To setup a Wi-Fi access point with an MT100EOCG and an MTPCIE Bluetooth Wi-Fi device:

1. Build **corecdp-wifi-ap-image** and flash it into the MT100EOCG.
2. Edit **/etc/udhcpd.conf** to configure the dhcp server.
3. Edit **/etc/hostapd.conf** to configure access point settings. Configure **ssid=<name>** with the access point name. Save hostapd.conf.
4. To start the access point, type `ocg-wifi-ap.sh start <desired IP address of AP>` on the MT100EOCG. For example:


```
ocg-wifi-ap.sh start 192.168.2.1
```
5. If you run a script like the example, the MT100EOCG acts as a cell router that allows Wi-Fi and Ethernet endpoints to access the Internet through EOCG's cellular PPP link. Uncomment the pppd call line for your device model.
6. Create a wireless network connection on a remote computer and configure it to use DHCP to obtain IP and DNS addresses.
7. Enable the wireless connection on the computer. Verify that your computer can communicate to the Internet using MT100EOCG as the access point.

Example Wi-Fi Access Point Script

```
#!/usr/bin/env bash

echo "Updating DNS, ppp scripts"
echo "nameserver 8.8.8.8" > /etc/resolv.conf

killall pppd && sleep 2

echo "Starting pppd"

#uncomment line below if gsm radio (H5, etc)
#pppd call gsm

#uncomment line below if cdma radio (EV3,etc)
#pppd call cdma

sleep 4

echo "Setting up iptables"

# Flush all the tables first
iptables -t filter -F
iptables -t nat -F
iptables -t mangle -F

iptables -t filter -P INPUT DROP
iptables -t filter -A INPUT -i lo -j ACCEPT
iptables -t filter -A INPUT -m state --state RELATED,ESTABLISHED -j ACCEPT

# accept all traffic from LAN
iptables -t filter -A INPUT -i eth0 -j ACCEPT
iptables -t filter -A INPUT -i wlan0 -j ACCEPT
```

```
iptables -t filter -P FORWARD DROP
iptables -t filter -A FORWARD -m state --state RELATED,ESTABLISHED -j ACCEPT
iptables -t filter -A FORWARD -i eth0 -o ppp0 -j ACCEPT
iptables -t filter -A FORWARD -i wlan0 -o ppp0 -j ACCEPT

iptables -t filter -P OUTPUT ACCEPT

iptables -t nat -A POSTROUTING -o ppp0 -j MASQUERADE

# turn on packet forwarding last
echo 1 > /proc/sys/net/ipv4/ip_forward
```

Using an MT100EOCG with an MTPCIE Bluetooth/Wi-Fi Device as Wi-Fi Client

To use the MT100EOCG with MTPCIE Bluetooth/Wi-Fi Device on the MTPCIE-DK1 as a Wi-Fi client:

1. On MT100EOCG, copy the file **wpa_supplicant.conf.example** to **/var/config** folder.

```
cp /etc/wpa_supplicant.conf.example /var/config/wpa_supplicant.conf
```
2. Edit **/var/config/wpa_mtechpc.conf** and change AP_Name and AP_Password to values required by your Wi-Fi network.

```
ctrl_interface=/var/run/wpa_supplicant
network={
    ssid=" AP_Name "
    scan_ssid=1
    # key_mgmt=NONE
    key_mgmt=WPA-PSK
    psk=" AP_Password "
    priority=1
}
```

3. Edit **/etc/network/interfaces** and uncomment the lines pertaining to wlan0 as shown below.

```
iface wlan0 inet dhcp
wpa-conf /var/config/wpa_supplicant.conf
wpa-driver nl80211
```

4. Reboot the MT100EOCG or type **ifup wlan0** at the console. MT100EOCG communicates through your Wi-Fi network.

Setting up Bluetooth with an MT100 EOCG and an MTPCIE Bluetooth/Wi-Fi Device

To setup MT100EOCG to control Bluetooth on a MTPCIE Bluetooth/Wi-Fi device, you need a remote Bluetooth device that supports serial communication. Then:

1. On the MTPCIE-DK1 developer board, position jumpers next to USB 3G port J4 to the 1,2 position.
2. Position jumpers next to USB Serial port J24 connector to the 2,3 position.
3. Position jumpers next to Bluetooth DB9 connector J14 to the 2,3 position.
4. Use a terminal program to connect the remote Bluetooth adapter to the computer's serial port.
5. On the MT100EOCG, type `rfcomm -S connect 0 xx:xx:xx:xx:xx:xx &`, where xx is the MAC address of the remote Bluetooth device. It returns a connected response similar to:

```
# rfcomm -S connect 0 00:A0:96:10:30:14 &
[1] 498
# Connected /dev/rfcomm0 to 00:A0:96:10:30:14 on channel 1
Press CTRL-C for hangup
```

6. Run a serial communication program, such as minicom, on the MT100EOCG which is configured to use `/dev/rfcomm0` as the serial device. You can now communicate with the remote Bluetooth serial device.

Setting up an External USB to MTPCIE Bluetooth Serial Interface

To set up an external USB to the serial Bluetooth interface on the MTPCIE-DK1 developer board when a MTPCIE radio is installed:

Note: The external USB connection terminates to a quad UART on the MTPCIE-DK1 board with one UART channel connected to the Bluetooth device.

1. On the MTPCIE-DK1 developer board, position jumpers next to Bluetooth DB9 connector J14 to the 2,3 position.
2. Position jumpers next to USB Serial connector J24 to the 1,2 position.
3. Position jumpers next to USB 3G connector J4 to the 1,2 position.
4. Power up the MTPCIE-DK1 developer board with the MTPCIE Bluetooth/Wi-Fi capable radio installed.
5. Connect computer USB port to the USB Serial J24 USB connector on DK1 board.
6. Use commands such as `dmesg`, `lsusb -v`, etc to find the ports Linux assigned to the quad uart on DK1. Record the port designation assigned to the second port. For example:

```
[ 126.376017] usb 7-1: new full speed USB device using uhci_hcd and address 3
[ 126.532263] usb 7-1: configuration #1 chosen from 1 choice
[ 126.582980] cdc_acm 7-1:1.0: This device cannot do calls on its own. It is not a modem.
[ 126.583024] cdc_acm 7-1:1.0: ttyACM0: USB ACM device
[ 126.590282] cdc_acm 7-1:1.2: This device cannot do calls on its own. It is not a modem.
[ 126.590322] cdc_acm 7-1:1.2: ttyACM1: USB ACM device
[ 126.592170] cdc_acm 7-1:1.4: This device cannot do calls on its own. It is not a modem.
[ 126.592215] cdc_acm 7-1:1.4: ttyACM2: USB ACM device
[ 126.595064] cdc_acm 7-1:1.6: This device cannot do calls on its own. It is not a modem.
[ 126.595115] cdc_acm 7-1:1.6: ttyACM3: USB ACM device
```

7. Copy the file `Tllnit_7.6.15.bts` to the `/lib/firmware` folder of the computer.

8. Install jumper JP86(labeled "BT_EN"), then remove it again to toggle the Bluetooth Enable signal for the MTPCIE.
9. Enter the following string, substituting the computer's tty port that corresponds to uart port B on MTPCIE-DK1:

```
hciattach -s 115200 /dev/ttyACM1 texas 3000000
```

10. On the Linux computer, enter:

```
hciconfig -a name
```

Example Response

```
ptg@ptg-desktop:~$ hciconfig -a name
hci0:    Type: UART
        BD Address: 1C:E2:CC:04:5C:C2 ACL MTU: 1021:4 SCO MTU: 180:4
        UP RUNNING PSCAN
        RX bytes:1013 acl:0 sco:0 events:30 errors:0
        TX bytes:883 acl:0 sco:0 commands:30 errors:0
        Features: 0xff 0xfe 0x2d 0xfe 0xdb 0xff 0x7b 0x87
        Packet type: DM1 DM3 DM5 DH1 DH3 DH5 HV1 HV2 HV3
        Link policy: RSWITCH HOLD SNIFF PARK
        Link mode: SLAVE ACCEPT
        Name: ""
        Class: 0x4a0104
        Service Classes: Networking, Capturing, Telephony
        Device Class: Computer, Desktop workstation
        HCI Ver: (0x6) HCI Rev: 0x0 LMP Ver: (0x6) LMP Subver: 0x1f29
        Manufacturer: Texas Instruments Inc. (13)
```

11. Verify the remote serial Bluetooth device is configured to wait for a connection.
12. Verify the remote Bluetooth device's MAC address is in the list of detected Bluetooth devices. Enter:

```
hcitool scan
```

Example Response

```
ptg@ptg-desktop:~$ hcitool scan
Scanning ...
    CC:55:AD:2B:53:FA    BB 9330
    00:18:E7:36:CF:91    DTMVW7JREI01
    00:A0:96:0F:B8:2A    SocketWireless
```

13. Enter the following, where xx represents MAC address of the remote Bluetooth device you set up previously:

```
rfcomm -S connect 0 xx:xx:xx:xx:xx:xx
```

To run rfcomm in the background add "&" to the end of the string as follows:

```
rfcomm -D connect 0 00:A0:96:0F:B8:2A &
```

14. Open another Linux terminal session and run a terminal program such as minicom at 3000000 bps attached to /dev/rfcomm0 port. Use minicom to communicate with your remote device.

Index

| | |
|--------------------------------------|-------|
| A | |
| account activation..... | 43 |
| activation | |
| cellular devices..... | 43 |
| antenna | |
| cellular devices..... | 40 |
| GPS..... | 41 |
| HSPA+..... | 40 |
| Wi-Fi RF..... | 41 |
| assembly diagram | 18 |
| B | |
| Bluetooth | 43 |
| build options | 43 |
| C | |
| cable | |
| debug | 31 |
| GPIO | 31 |
| CAD drawing..... | 45 46 |
| CE mark | 35 |
| Chinese hazardous substances | |
| Chinese version..... | 39 |
| English version | 38 |
| C programming | |
| close | 69 |
| open | 67 |
| read..... | 68 |
| test program | 70 |
| write..... | 69 |
| D | |
| debug cable..... | 31 |
| developer board..... | 16 |
| device | |
| maintenance | 32 |
| dialing restrictions..... | 36 |
| drawing | 45 46 |
| E | |
| electrical | |
| characteristics | 49 |
| electromagnetic interference | 14 |
| electrostatic discharge | 15 |
| EMI | 14 |
| ESD | 15 |
| European Community Directives | 35 |
| F | |
| frequency bands | 59 |
| G | |
| general regulatory..... | 36 |
| GPS | |
| antenna..... | 41 |
| ground plane..... | 14 |
| H | |
| handling precautions due to ESD..... | 15 |
| hazardous substances | 36 |
| HSPA+..... | 34 |
| antenna..... | 40 |
| HSPA+21..... | 43 |
| I | |
| IMEI | 34 |
| install | |
| SIM card | 31 |
| installing | |
| device on board | 31 |
| J | |
| jumpers | 30 |
| L | |
| labels | 34 |
| Linux | |
| building driver..... | 61 |
| C programming | 67 |
| driver..... | 43 |
| install..... | 60 |
| PPP connection | 66 |

| | | | |
|------------------------------------|----------|--|--|
| shell commands | 66 | | |
| troubleshoot driver | 60 | | |
| M | | | |
| maintenance | 32 | | |
| mechanical drawing | 45 46 | | |
| N | | | |
| noise suppression..... | 14 | | |
| P | | | |
| PC board layout..... | 14 | | |
| pinout | 50 | | |
| USB..... | 13 | | |
| pinout table..... | 8 | | |
| standard | 11 | | |
| power connection | 31 | | |
| power draw | 56 | | |
| PTCRB | 34 | | |
| R | | | |
| radio frequency interference | 32 | | |
| receiver features | 58 | | |
| RoHS | 36 | | |
| S | | | |
| safety | | | |
| RF interference | 32 | | |
| vehicle | 32 | | |
| safety standards | 14 | | |
| SIM card | 31 | | |
| specifications..... | 47 | | |
| T | | | |
| transmitter features..... | 58 | | |
| U | | | |
| uninstall..... | 64 | | |
| USB..... | 13 64 | | |
| design consideration..... | 15 | | |
| driver download..... | 61 | | |
| notes | 61 | | |
| USB driver | | | |
| install..... | 60 62 63 | | |
| uninstall | 64 | | |
| user responsibility | 32 | | |
| V | | | |
| vehicle safety | 32 | | |
| Vista | 62 64 | | |
| W | | | |
| Wi-Fi | 43 | | |
| Wi-Fi RF specifications | 41 | | |
| Windows | | | |
| release notes..... | 61 | | |
| USB driver download | 61 | | |
| USB driver release notes..... | 61 | | |
| Windows 7 | 62 64 | | |
| Windows 8 | 62 | | |
| uninstall | 64 | | |
| Windows XP | 63 64 | | |
| X | | | |
| XP | 63 | | |